



PULLEY LOCATIONS

- A. BUSHINGS WELDED TO LONGERON JUST AFT OF S-2 BOTTOM CROSSING TUBE.
- B. BUSHINGS WELDED TO NEAR THE CENTER OF THE BOTTOM CROSSING TUBE OF THE SEAT TRUSS.
- C. #11 HOLES LOCATED NEAR THE CENTER OF THE S-3 BOTTOM CROSSING TUBE. HOLES ARE DRILLED AT AN ANGLE.
- D. #11 HOLES LOCATED NEAR THE CENTER OF THE S-3 TOP CROSSING TUBE. HOLES ARE DRILLED AT AN ANGLE.
- E. CONTROL TEE. SEE PUSH PULL TUBES.